

Caring For Your Floor Graphics

Proper care of your floor graphics will help keep them looking their best. Use routine floor maintenance procedures and equipment to maintain graphic(s).

Wax the graphics soon after application

If you apply the graphics to a floor that is routinely maintained using buffing or scrubbing equipment, wax the graphic as soon as possible after applying it to the floor. This protects the graphics from premature wear due to floor maintenance.

- 1: Select a floor finish or wax that meets or exceeds the 0.5 Static Coefficient of Friction Value using the ASTM D-2047 Test procedure.
- 2: Clean the graphics prior to waxing
- 3: Follow the manufacturer's recommendations for applying the floor finish or wax.
- 4: Do not use buffing equipment over graphics unless they are waxed regularly. If high-speed, propane-type buffers are used, we recommend that you apply four to six coats of wax to the graphic before buffing it. The multiple coatings of wax reduce the chance of the graphic's edge wearing prematurely during buffing.

Following the application and waxing, if used, keep the graphic and surrounding floor surface clean and dry for at least four hours; do not scrub or buff the area during that time.

*To reduce the risk of tripping, remove and replace the entire graphic if there is any lifting from the floor surface.