

Wall Prep

Prior to installing your mural, proper wall preparation is the key to getting great results.

1. Basic steps for wall preparation:

- A) Remove old wall covering if applicable.
- B) Remove flaking paint.
- C) Repair any defects in the wall surface; patch nail holes, sand and paint.

2. Allow two weeks for paint to cure.

3. Remove picture hooks, light fixtures, switch plates, & outlet plates, etc

4. Clean wall with a diluted isopropyl alcohol solution (~70%)

Special Notes:

For best adhesion when installing a vinyl wall mural, paint wall with two coats of satin or semi-gloss paint. Flat paint or primer are not recommended.

Allow a minimum of 7 days for the paint to cure before installing your mural, two - three weeks are preferred.

Vinyl wall applications will not hide imperfections in underlying finish.

Heavily textured walls may require a textured wall film.

If you have questions about preparing walls for installation,
call Mile High Graphics at 720-583-6401 or email us at info@milehighgraphics.com